



RAMSAUER®
DICHTSTOFFE

504 UNIVERSAL REINIGUNGSTÜCHER (CLEANING TISSUES)

PRODUCT INFORMATION

Visual appearance: tissues

Colour: white

Odour: fruity

Tensides: neutral, amphoteric

Packaging: Cans of 150 or 75 units.

Storage: Always keep container closed in order to prevent the tissue from drying out.

CHARACTERISTICS

The cleaning tissues serve for removing sealing compounds in slightly cured and pasty state from tools and working surfaces. Particularly suitable for silicone, polyurethane or polysulphide sealants. They can also be used for removing paints, linseed oil putty, resins and adhesives which have not yet formed a film. The cleaning tissues are impregnated with a solvent on an aqueous basis. Thus, the tissues which are also absorbent remove the aforementioned products and at the same time clean the surfaces of the objects. They meet the requirements of the applicable EU Directives for cosmetics.

ADVANTAGES

- Reduced cleaning times
- Highly efficient; high cleaning power with sealing compounds, paints, adhesives, and resins which have not cured yet
- Particularly suitable for the following contaminated substrates: plastics, powder-coated and paint-coated surfaces, metals, and glass
- Suitable for a wide variety of cleaning jobs
- Easy to handle, pleasant lemon odour
- Contains lanoline
- Conventional packaging
- Cost efficient
- Long storage life in closed container

PRACTICAL APPLICATION

- Wherever contamination with sealants occurs
- When sealing glass
- Sealing in general
- Automotive industry
- Glazing work and restoration
- Aviation industry

INSTRUCTIONS FOR USE

The cleaning tissues are used to remove excess sealants, resins, paints etc. which have not cured yet. In this way the cleaning periods are shortened and the risk of further contamination by dirty tools is reduced. The product is particularly suitable for removing fresh paint from tools and

contaminated surfaces during painting. Also suitable for removing resins. The cleaning tissues will not remove any cured sealants, paints or adhesives. Simply take a tissue out of the can and clean the object. Use a second tissue if required.





RAMSAUER®
DICHTSTOFFE

GENERAL INFORMATION

- Harmless – meets the requirements of current EU directives
- Environmentally friendly
- Symbol: not subject to labelling requirements
- Product: not classified as a hazardous substance
- First aid measures: after inhalation: no particular measures required
- After eye contact: rinse with plenty of water for approx. 15 minutes

HAZARD ADVICE

The product is not a hazardous substance within the meaning of the German Hazardous Substances Ordinance. For further information refer to the Safety Data Sheet.

SAFETY ADVICE AND ADVICE FOR DISPOSAL

Consult the current EC Safety Data Sheet which is available at any time on our website at www.ramsauer.at.

LIABILITY FOR DEFECTS

The information provided including but not limited to the proposals for processing and using our products is based on our knowledge and experience, usually at the time of going into print. The results of work may deviate from this information depending on the specific circumstances, in particular with respect to substrates, processing and environmental conditions. Therefore, neither this information nor any oral counselling shall constitute warranty or give rise to any liability on whatever legal ground for any specific result

of work, unless we acted intentionally or by gross negligence. Ramsauer warrants that its products will have the technical characteristics according to the Technical Data Sheets up to their expiry date.

Product users must consult the latest data sheet which is available upon request. Our current General Terms and Conditions apply which are available for download on our website www.ramsauer.at.



QUALITY YOU CAN RELY ON

Ramsauer GmbH & Co KG, 4822 Bad Goisern/Hallstätter See, Sarstein 17, Austria

Phone: +43 (0)6135 8205-0, Fax: +43 (0)6135 8323 - Email: office@ramsauer.at - Internet: www.ramsauer.at